



UV LED 222nm 222nm UV LED

電圧(V)	DC 24V
光束密度(lm/w)	125
光束径(φ)	φ10
照射距離	Far UVC 222nm 照射距離 約 10cm
光束径(φ)	4000
光束径(φ)	10000
照射距離	約 10cm, 約 20cm, 約 30cm, 約 40cm, 約 50cm, 約 60cm, 約 70cm, 約 80cm, 約 90cm, 約 100cm
照射距離	DC
照射距離	約 10cm, 約 20cm









222nm UVC 20W Module


Shenzhen Newplanet Technology Co., LTD

www.irlight.cn


Attn: Judy Huang 0086-13760193325

E: irlightsales02@hotmail.com


222nm Module Size



222NM Lamp Structure




Lamp Module Structure



A: 84.5MM
B: 36MM Diameter


C: 138.6MM
D: 40MM

Wavelength Spectrum




Installation with ballast

The 222nm must connect with ballast to longer lifetime of 222nm lamp



- 222 nm lamp both side connected with a ballast input . And out contact with a suitable adapter to suit for city Electricity.

Lifetime State



Application

Metre, Hospital, Library, Restaurant, Store, Super Market Hall. Hotel....



●Warning

- During lighting, the external network will generate high voltage. Please do not touch it with your hands.
- When installing or removing the lamp tube or cleaning the lamp box, be sure to turn off the main power supply. (avoid electric shock) In the light box with appropriate specifications, be sure to use the specified power lamp. (avoid overheating of the lamp box, damage of the lamp tube, short service life, etc.)
- Do not use it around ignition substances such as organic solvents. (avoid fire and explosion)
- Do not let paper, cloth, etc. close to or cover the lamp tube or lamp box. (avoid fire)

☐☐ ☐☐☐☐ **222nm UVC** ☐☐ ☐☐ ☐☐☐, ☐☐☐ ☐☐☐, ☐☐ ☐☐, ☐☐ ☐☐ ☐☐ ☐☐☐☐☐.